

KR Fuel Oil Change Over Program Version 1.0

User's Manual

2014

Korean Register of Shipping

Index

1. Installation	1
2. KR-FOCO Program User Guide	3


Korean Register assumes no liability for damages, direct or consequential, which may result from the use of the Software, even if Korean Register has been advised of the possibility of such damages. However, if a contract is signed with Korean Register or its relevant entity for the provision of this information, only in that case, any accountability or liability is completely on the terms and conditions set forth in the contract.




1. Installation

1. Things to check before installation

- This program is for Windows system only.
- This program requires approximately 18.0 MB of hard disk space. Check your hard disk space before installation.
- MS-Word program should be pre-installed.




2. Installation





Installation	Instruction
	<p>► Click "setup.exe". When following screen appears, click "Next".</p>

Installation	Instruction
	<p>► Click "Browse" to select the installation directory, then click "Next".</p>
	<p>► Click "Next" to start the installation.</p>
	<p>► Click "Close" when the installation is completed.</p>


2. KR-FOCO Program User Guide

Program operation is as follow :


Status	Instruction
	<p>► 1. Click the  "KR-FOCO".</p>
	<p>► Ship Name: Enter the name of ship.</p> <p>► Gross Tonnage : Enter the ship's Gross Tonnage.</p> <p>► Class No. : Enter the ship's classification number.</p> <p>► Flag : Enter the ship's flag.</p> <p>► IMO No. : Enter the ship's IMO number.</p> <p>※ <u>Where ship information is not available, enter the Ship Name only.</u></p>

Status	Instruction
	<p>► Fuel Oil Consumption Rate Enter the F.O Consumption rate of Main Engine, Generator Engine and Aux. Boiler</p> <p>► HFO Tank : 1) Enter the amount of the HFO Settling Tank, HFO Service Tank and HFO Service System including Piping System 2) Enter the Sulphur content and Price of HFO</p> <p>► LSFO Tank : Enter the Sulphur content and Price of LSFO</p>
	<p>► 1. Click  "Run Calculation".</p>
	<p>► Check the result of the calculation</p> <p>Max. Changeover Time : 24Hrs</p>


Status




Instruction

► Click  "Export to word" to print the result calculation.




► Save the files



► Result of calculation (Ms-Word format) appears.



The icon's function is described as follow

 [Open]	<ol style="list-style-type: none"> Click the icon. When te [Open KR FOCO file] dialog box appears, select the folder you wish to choose from [Directory]. Select the file(*.xml) you wish to choose from the file list box. Click [Open]. The selected file will appear on the screen.
 [Save]	<ol style="list-style-type: none"> Click the icon. When the [Save KR FOCO file] dialog box appears, choose a drive from [Directory]. In the file list window, select a folder in which the file is to be saved. Enter the file name in the [File Name] dialog box. Click [Save].
 [Save as]	<ol style="list-style-type: none"> Click the icon. When the [Save as FOCO file] appears, enter a new name in the [File name] dialog box. Click [Save].